

CAR WASHER	
S.NO	Description
1	Distance Bush
2	Key
3	End Disc
4	Gasket
5	water Filter
6	Aluminium Gun
7	Water Gun
8	Seal Kit
9	Plunger
10	Connecting Rod
11	Spring
12	NRV Set
CAR WASHER HOSE	
1	BS 5/16 R1 6MTR M + ST hose
2	BS 5/16 R1 8MTR M + ST hose

GREASE PUMP SPARES	
S.NO	Description
1	Piston Pipe
2	Piston Rod
3	S S Valve Seat
4	Follower
5	T rod with Nut
6	Plunger Rod
7	Conveyor Piston
8	Pressure Housing
9	Cap
10	Top Piece
11	Brass items
12	Filter Holder
13	Filter
14	Control Head
15	Pressure Pipe
16	Cover Pipe
17	Connecting Rod (50Kg)
18	Air Cyclinder
19	Air Piston
20	Valve Body
21	Flange
22	Control Assembly
23	Support Stopper
24	1/4 inch Connector
25	Outlet Union
26	Radius Piece Top
27	Bottom Piece

28	12 inch Lock Nut
29	12mm washer
30	Pressure Adjust Bolt
31	Spazer
32	Slider Seating Plate
33	Slider
34	Lock Housing
35	Control Jaw
36	Rotary Nut
37	Pressure Ring
38	Feeder
39	Suction Pipe
40	Oring packing